


LED 摄影灯

用户手册

RGB V1.0



— 专业LED补光灯 —

感谢您选择我们的产品，请仔细阅读说明书并按手册使用。


产品特性

- 1.使用高显指LED灯组合,发热量小使用寿命长。
2.亮度及色温可调节。
3.内置锂电池,可以重复充放电。
4.采用专业的LED驱动芯片,光线稳定,效率高达93%。
5.高亮度,最大1000流明,适用于需要补充光线的情况。
6.可调节全色0-360°色温及颜色饱和度。
7.21个预设环境效果。
8.带三角架安装螺母(1/4接口),可以搭配三脚架使用。
9.应用:摄影照明、应急照明等。

配置

LED灯 : 1只 充电USB线 : 1条
说明书 : 1本

部件名称




- A OLED显示屏
B 功能键
C 设定拨盘/选择按钮
D 光亮度调节旋钮
E 开关
F Type-C充电接口
G 1/4寸螺丝口

安装摄影灯

- 1.通过三脚架螺丝与补光灯螺丝孔对准插入,旋转锁定环固定。
2.将已安装热靴座的产品插入相机热靴口,使灯光调至合适位置。

按键操作使用方法



- 1.拨动开关键开机。
2.开机状态单击功能键,可选择CCT/HSI/EFFECT三种模式。
3.CCT模式:拨动设定拨盘可调节色温(2500K~9900K),转动光亮度旋钮调节亮度(1%~100%)。
4.HSI模式:按下设定拨盘来选择H(色调)和S(饱和度),显示屏上“>”为当前选择,拨动设定拨盘来调节H(色调)0~360°拨动设定拨盘来调节S(饱和度)0~100,转动光亮度旋钮调节亮度(1%~100%)。
5.充电时,显示屏会显示当前电量和充满所需的时间。
6.使用时,显示屏会显示当前电量和可持续使用时间,当显示的电池电量已空时需要立即充电。
7.切换到EFFECT模式档位,在EFFECT模式下按下设定拨盘依次选择预设环境效果组别,拨动设定拨盘依次选择该组别下的预设环境效果,转动光亮度调节旋钮,调节预设环境效果亮度(1%~100%)。

预设环境效果名单

- A.闪光灯/电视屏幕光 E.慢速渐变/中速渐变/快速渐变
B.蜡烛/火焰1/火焰2 F.烟花1/烟花2/烟花3
C.警车/救护车/消防车 G.俱乐部1/俱乐部2/浪漫
D.频闪1/频闪2/频闪3

规格

Table with 2 columns: Parameter and Value. Includes Power (10W), Battery (3.7V 5200mAh), Light angle (120°), Color temp (2500~9900K), Chromatic index (RA>95), Illuminance (1000LM), Dimension (122*118*31mm), Weight (240g), Operating temperature (0~40°C).

注:此灯具光源是不可替换,当光源到其寿命时,应替换整个灯具。

注意事项

- 1.请勿将本产品在高温或极端环境中放置或者使用,请勿放在阳光下暴晒。
2.避免将本产品放置在酒精、汽油、易燃或挥发性溶剂附近,这些溶剂会引起火灾或损坏摄影光。
3.不要将本产品暴露在水或液体中,造成短路和损坏产品。
4.请勿擅自拆卸本产品,请勿大力震动、敲打、撞击本产品。
6.儿童请在监护人员的陪同下使用该产品,避免直射、伤害眼睛。
7.请至少3个月为本产品充满电一次。
8.本产品点亮时请不要盯着灯珠,避免灯光直射,伤害眼睛。
9.正常工作均有可能显产品温度升高,使用期间或使用完毕后,请小心取拿,避免烫伤。
10.产品开灯显发光功率较大,请勿将发光面覆盖,以避免造成补光灯损坏或意外事故发生。



注意:本产品最终解释权归利亚迪公司所有。


保修卡

Warranty card form with fields for user information, product information, and repair records.

LED Video Light

User manual

RGB V1.0



— Professional LED light —

Thank you for choosing our product, please read the instructions carefully and press the manual use it.


Product Feature

- 1. Use high display LED lamp combination, low heat and long service life.
2. The brightness and color temperature are adjustable.
3. Built-in lithium battery, which can repeatedly charge and discharge.
4. Professional LED drive chip with stable light and up to 93% efficiency.
5. High luminosity, with a maximum of 1,000 lumens. Suitable where supplementary light is needed.
6. Adjustable full color 0-360 tone and color saturation.
7. 21 preset environment effects.
8. With tripod mounting nut (1 / 4 interface), available with tripod.
9. Application: photography and lighting, emergency lighting.

Configure

LED light: 1PCS USB Cable: 1PCS
Instruction: 1PCS


Part name



- A The OLED display screen
B Function key
C Set the dial / selection button
D Lighting adjustment knob
E ON/OFF
F Type-C charging interface
G 1 / 4 inch nut

Install the photo lights

- 1. Aign with the hot boot screw and rotate the lock ring.
2. Place the hot boot installed product into the camera hot boot port to adjust the light to the appropriate position.



- 1. Turn on the switch.
2. Click the function key to select the three CCT / HSI / EFFECT modes.
3. CCT mode: dial adjustable color temperature (2500K ~ 9900K), turn the illumination knob to adjust the brightness (1% ~ 100%). The display displays color / Mid brightness.
4. HSI mode: Press the set dial to select the H (tone) and S (saturation), display on-screen “>” dial to adjust H (tone for the current selection) 0 ~ 360° pull the set dial to adjust the S (saturation) 0 ~ 100 and turn the illumination knob to adjust brightness (1% ~ 100%).
5. When charging, the display displays the current charge and the time required to fill.
6. When used, the display displays the current power and sustainable usage time, when displayed immediately charge is required when the battery is empty.

- 7. Convert to EFFECT mode gear and select pressing the set dial in EFFECT mode. Select the preset environment effect group, dial the setting dial and select the preset ring under the group border effect, turn the illumination adjustment knob to adjust the preset ambient effect brightness (1% ~ 100%).

Preset environment effects list

- A: Flash / flash mob / TV screen light
B: Candle / Flame 1 / Flame 2
C: Police car / Ambulance / Fire truck
D: Strobe Light 1 / Strobe Light 2 / Strobe Light 3
E: Chase slow / Chase mid / Chase fast
F: Fireworks 1 / Fireworks 2 / Fireworks 3
G: Music 1 / Fun 2 / Romance

Specifications

Table with 2 columns: Parameter and Value. Includes Power dissipation (10W), Battery voltage (3.7V 5200mAh), Light angle (120), Color temperature (2500~9900K), Chromogenic index (RA>95), Illuminance (1000LM), Dimension (122*118*31mm), Weight (240g), Operating temperature (0~40°C).

Notes

- 1. Do not place or use this product in high temperature or extreme environment, and do not expose it to the sun.
2. Avoid placing photographic light near alcohol, gasoline, flammable or volatile solvents, which can cause fire or damage the photographic light.
3. Do not expose the equipment to water or other liquids, causing short circuit and damaging the product.
4. Please do not disassemble the product without authorization, and do not shake, knock or impact the product vigorously.
6. Children should use the product with the help of guardians to avoid direct exposure and eye injury.
7. Please fully charge the product for at least 3 month.
8. Please do not stare at the lamp bead when the photography lamp is on, to avoid direct light and eye injury.
9. In normal operation, the temperature of the product may rise. Please take it carefully during use or after use to avoid scalding.
10. Before using this product, please check its voltage demand to avoid damage caused by using the wrong voltage or power.
11. The product has high luminous power when it is turned on. Please do not cover the luminous surface to avoid damage to the light compensating lamp or accident.



Note: The final interpretation right of this product belongs to LYADI Company.

Warranty card

Warranty card form with fields for user information, product information, and repair records.