

2.开机状态单击功能键,可选择CCT/HSI/EFF三种模式 3.CCT模式:按选择键可选择调色温或调亮度,显示屏上"▶" 为当前调节参数, "+-"按键增加或减少该参数。 4.HSI模式:按选择键可选择调色调、色彩饱和度、亮度 显示屏上"▶"为当前调节参数, "+-" 按键增加或减少该 参数。色调调节范围为0~360°, 色彩饱和度调节范围为0~ 5.充电时,显示屏会显示当前电量和充满所需的时间。

6.使用时,显示屏会显示当前电量和可持续使用时间, 当显示的 电池电量已空时需要立即充电。 7.当蓝牙状态不停闪烁时,表示设备未连接或断开连接;连接成

8.转换到EFF模式档位,在EFF模式档位按选择键就是调节 转换24种预设环境效果或亮度。

预设环境效果名单

A:闪光/快闪/电视屏幕光 E:慢速渐变/中速渐变/快速渐变 B:蜡烛/火焰1/火焰2 C:警车/救护车/消防车 D:频闪1/频闪2/频闪3

F:烟花1/烟花2/烟花3 G:俱乐部1/俱乐部2/浪漫 H:音乐/自定义呼吸光/自定义频闪光 (自定义光效需要在APP中设置)

规格

功率	24W	
电池	7.4V 5200mAh	
光照角度	45°	
色温	2500-9900K	
显色指数	RA>95	
0.5m光照度	7050lux	
尺寸	607*101*54mm	
重量	855g	
使用温度	0~40°C	

注意事项

- 1.请勿将本产品在高温或极端环境中放置或者使用,请勿放在 阳光下暴晒。
- 2.避免将本产品放置在酒精、汽油、易燃或挥发性溶剂附近
- 这些溶剂会引起火灾或损坏摄影光。 3.不要将本产品暴露在水或其他液体中,造成短路和损坏产品。
- 4.请勿擅自拆卸本产品,请勿大力震动、敲打、撞击本产品。
- 6.儿童请在监护人员的陪同下使用本产品,避免直射、伤害眼
- 7.请至少3个月为本产品充满电一次。
- 8.摄影灯点亮时请不要盯着灯珠避免灯光直射,伤害眼睛。
- 9.正常工作均有可能使产品温度升高,使用期间或使用完毕后, 请小心取拿,避免烫伤。
- 11.产品开灯是发光功率较大,请勿将发光面覆盖,以避造成补 光灯损坏或意外事故发生。



本产品最终解析权归利亚迪公司

保修卡

用户名称: 联系电话: 联系地址: 产品信息 销售日期:

产品维修记录送检时间

用户信息

送修时间	维修中心名称	故障及处理情况	完成日期
	1		

经销商信息

联系地址:

LED Video Light

User Manual



— Professional Led Fill Light —

■ Features

LED灯

防眩光片

: 1个

: 2个

: 1片

Using 72 high-quality non-flashing LEDs (24pcs white LEDs, 24pcs warm LEDS, 24pcs RGB LEDs) with max power 24W, 2500K-9900K color temperature, CRI > 95

充电USB线

柔光片

: 1本

: 1片

[Precision Circuit Control]

With built-in professional LED driver chip and accurate dimming circuit, there is no ripples or stroboscopic phenomenon when shooting which perfectly matches with high-lumen SMD LEDs to reach more accurate brightness, High color rendering index, soft and uniform light, especially suitable for live broadcast, selfe stilife shooting, short video recording,

[Three Usage Modes, Colors can be Adjusted as You Like]

With CCT cold and warm mode, the adjustable range of color temperature Is 2500 K-9900K. HSI color mode has 36,000 finely adjustable colors. HUE is adjustable from 0-360, and SAT saturation is adjustable from 0-100. What's more surprising is that the EFFECT mode presets 24 scenarios . All three modes can be matched with 1-100 brightness adjustment

[24 Dynamic Effects in EFFECT Mode]

8 large groups of different scene simulations, each group contains 3 erects, which can be combined as you like and the brightness is adjustable Help take photos or photography to render different atmospheres and meet the needs of the storyline

[Built-in High-Capacity & Rechargeable 5200mAh Battery]

Rest assured to use it in outdoor or indoor. Using Class A lithium ion batteries , and it also supports pass-through charging With USB-C 9V / 2A


[Fashionable Appearance with Aluminum Alloy Shell]

The whole shell adopts aluminum alloy oxidation proc ess with OLED

■ Caution

- Use original or certified cables.
- Do not disassemble or repair it by yourself. Avoid lightning strikes, knocking and dropping.
- Please charge fully every 3 months to extend the battery life.
- Avoid extreme temperatures.
- Do not expose to water or chemicals.

■ Product Interface




I/4 inch Screw Hole

Button"+" A Power Button B Function Adjustment Button"-" **(** USB-C Charging Port Selection Switch **D** OLED Display


■ Specification

Color Tern peratu re Range: 2500K-9900K (±250K) RGB Hue (HSI): 0-360°Full Color Adjustable Color Saturation Adjustment: 0-100 Brightness Adjustment: 1-100% Illumination: 7050lux (0.5m 9900k) Color Rendering Index(CRI): Ra>95 Mode: CCT/HSI/Effect Mode Effect Mode Scene: 24 Scenes Supportable Built-in battery: 7.4V/5200mAh lithium battery Fixed Interface: 1/4inch Screw Hole Shell Material: Aluminium Alloy Dimensions: 607*101*54mm Weight(Approx): 1.1kg

■ Display Interface



- 2 Current Mode (CCT/HSI/EFFECT) Battery Level
- 4 Current adjustment items **⑤** Color Temperature⊗(CCT Mode) **⑥** Brightness∜(CCT Mode)



8 Hue: H (HSI Mode)

Preset Scene Effect Group (EFFECT Mode) Preset Scene Effect Name (EFFECT Mode) BLUETOOTH

■ Usage

Stir the Power Button (a), then the video light turns on/off. When charqing and discharging, it will turn on and off automatically, noneed to stir the button.

2.Mode Switch Press Power Button **®** to select different modes(CCT/HSI/EFFECT) 3.CCT Mode

Press the button • to select the color temperature and brightness. 1.Press"+" or"-" to adjust the brightness (1%- 100%)

2.Press"+" or "-"to adjust the coior temperature (2500K-9900K) ▶ & 4500K - ☆-100%

4.HSI Mode

Press the button to select H (hue), S (saturation), brightness. 1.Press" + " or" - " key to adjust H(tone) 0-360° 2.Press"+" or"-" to adjust S(saturation) 0- 100 3.Press"+" or"-" to adjust (brightness) 1%-100%

▶ H:360° - - 100%

5.EFFECT Mode Press the button **©** to select the scene effect group and scene effect name or brightness. Turn the **1** or **1** to adjust the needed parameter

◯ 2.2h 🚻 🔰 EFFECT -\\;_100% FLASH

■ 24 Dynamic Sence Effect

Group B: Candle/Flame 1/Flame 2 Group C: Police/Ambulance/Fire truck Group D: Strobe Lights 1/Strobe Lights 2/Strobe Lights Group E: Chase slow/Chase mid/Chase fast Group F: Fire work 1/Fire work 2/Fire work 3 Group G: Club 1/Club 2/Romantic Group H: Music/Wave 1/Wave 2

■ How to Charge

Equipped with a 9V USB-C input, please correctly connect the charging cable to the power supply unit.

The OLED display will show the charging status when charging. The maximum charging current of this product is 9V2A, so the recharging time depends on the charging adapter you used.

■ How to Install the Cole Shoe

1. Align the screw of the cold shoe adapter with the 1/4 inch screw hole of this product

2. Turn the locking ring clockwise to fix the cold shoe adapter on the praduct.

■ How to Install the Camera

1. Turn off the LED Video Light.

2.Slide the bottom of the adapter of the product with the adapter nstalled into the camera hot shoe or cold shoe mount

■ How to Remove the Camera

1.Turn off the LED Video Light.

2. Turn the locking ring clockwise and remove the adapter from the camera/cold shoe mount.

■ What's in the box?

5.Soft light plate 6.Soft light plate 4.Grid plate 7.Carrying bag

■ Warning

Inappropriate use may cause product damage or pose potential physical injury and potential physical injury and property loss.

■ Safety Warning

•Please do not use LED to illuminate human eyes at close range, otherwise it may temporarily affect your evesight. We hiahly recommend you use it on Im away or consider using a diffuser. •Please do not place this product near alcohol or flammable materials .

• This product is not yYaterproof or dust-proof, please do not place

this product near liquids • Please use a soft cloth and neutral detergent to clean it. Please do not use alcohol or corrosive solventsto clean it.

•Please store and use it below 40 degrees, and pay more attention when you use it outdoors for a long time under sunlight. •Please do not use this product outdoors for a long time to avoid

overheating and possible damage. •with a built-in lithium battery, please do not disassemble, hit or

burn this product by yourself. •Please use certified charging cable and adapter to recharge it to

• Please fully charge it every three months to prolong battery life. •If you do not use this product for a long time, please be sure to charge it before using it again. •The performance of the lithium battery will gradually decrease with

the use of this product, so as the using time. •When the LED is used at the same time durina charging, to avoid overheating, the product may not work normally or automatically shut down due to overheating.